

AWK-5222

Quick Installation Guide

Moxa AirWorks

Third Edition, June 2014



© 2014 Moxa Inc. All rights reserved.

P/N: 1802052220012

Overview

The AWK-5222 dual-RF wireless AP/Bridge/Client provides a flexible and highly reliable solution for your industrial wireless networks.

The AWK-5222 is rated to operate at temperatures ranging from 0 to 60°C for standard models and -40 to 75°C for extended temperature models, and it is rugged enough for industrial applications.

With two independent RF modules, the AWK-5222 supports a greater variety of wireless configurations and applications, and the redundant wireless connections increase the reliability of your entire wireless network.

The AWK-5222's two DC power inputs make the power supply more reliable, and it can also be powered via PoE for easier deployment.

Package Checklist

Moxa's AWK-5222 is shipped with the following items. If any of these items is missing or damaged, please contact your customer service representative for assistance.

- 1 AWK-5222
- 2 Swivel-type Antennas (2dBi, RP-SMA, 2.4&5GHz)
- 1 Quick Installation Guide
- 1 Software CD
- 1 Moxa Product Warranty Booklet
- 1 Cable Holder with a Screw
- 2 Protective Caps

Installation and Configuration

Before installing the AWK-5222, make sure that all items in the Package Checklist are in the box. In addition, you will need access to a notebook computer or PC equipped with an Ethernet port. The AWK-5222 has a default IP address that you must use when connecting to the device for the first time.

Step 1: Select the power source

The AWK-5222 can be powered by a DC power input or PoE (Power over Ethernet). The AWK-5222 will use whichever power source you choose.

Step 2: Connect the AWK-5222 to a notebook or PC

Since the AWK-5222 supports MDI/MDI-X auto-sensing, you can use either a straight-through cable or crossover cable to connect the AWK-5222 to a computer. If the LED indicator on the AWK-5222's LAN port lights up, it means the connection is established.

Step 3: Set up the computer's IP address

Set an IP address on the same subnet as the AWK-5222. Since the AWK-5222's default IP address is 192.168.127.253, and the subnet mask is 255.255.255.0, you should set the IP address of the computer to 192.168.127.xxx and subnet mask to 255.255.255.0.

Step 4: Use the web-based manager to configure AWK-5222

Open your computer's web browser and then type `http://192.168.127.253` in the address field to access the homepage of the web-based management. Before the homepage opens, you will need to enter the user name and password. For first-time configuration, enter the default user name and password and then click on the **Login** button:

User name: **admin**
Password: **root**



ATTENTION




For security reasons, we strongly recommend changing the password. To do so, select **Maintenance → Password**, and then follow the on-screen instructions.

Step 5: Select the operation mode for the AWK-5222

By default, the AWK-5222's operation mode is set to Wireless Redundancy. You can change the setting in **Wireless Settings → Operation mode** if you would like to use the Wireless Bridge or AP-Client mode.

NOTE To make the change effective, you must click **Save Configuration** to save the change or **Restart → Save and Restart** button to apply all changes).


Panel Layout of the AWK-5222



1. Grounding screw
2. Terminal block for PWR1, PWR2, relay, DI1, and DI2
3. Reset button
4. Heat dissipation orifices
5. AUX1 and AUX2 antenna ports
6. System LEDs: PWR1, PWR2, PoE, FAULT, and STATE LEDs
7. WLAN LEDs: WLAN 1 and WLAN2 LEDs
8. RS-232 console port
9. 10/100BaseT(X) RJ45 Port : LAN1 and LAN2
10. 10M LED
11. 100M LED
12. MAIN 1 antenna port
13. MAIN 2 antenna port
14. Model name
15. Screw hole for wall mounting kit
16. DIN-Rail mounting kit

Mounting Dimensions

Unit = mm (inch)




DIN-Rail Mounting

The aluminum DIN-Rail attachment plate should be fixed to the back panel of the AWK-5222 when you take it out of the box. If you need to reattach the DIN-Rail attachment plate to the AWK-5222, make sure the stiff metal spring is situated towards the top, as shown in the figures below.


STEP 1:

Insert the top of the DIN-Rail into the slot just below the stiff metal spring.



STEP 2:

The DIN-Rail attachment unit will snap into place as shown below.




To remove the AWK-5222 from the DIN-Rail, simply reverse Steps 1 and 2.

Wall Mounting (optional)

For transportation applications that require an EN50155 certification report, you should purchase the optional wall mount for the AWK-5222, since the wall mount has passed EN50155 testing. The wall mount is also convenient for other applications that require mounting the AWK-5222 to a wall.


STEP 1:

Remove the aluminum DIN-Rail attachment plate from the AWK-5222, and then attach the wall mount plates with **M3** screws, as shown in the adjacent diagrams.



STEP 2:

Mounting the AWK-5222 to a wall requires 4 screws. Use the AWK-5222 device, with wall mount plates attached, as a guide to mark the correct locations of the 4 screws. The heads of the screws should be less than 6.0 mm in diameter, and the shafts should be less than 3.5 mm in diameter, as shown in the figure at the right.




Do not screw the screws in all the way—leave a space of about 2 mm to allow room for sliding the wall mount panel between the wall and the screws.

NOTE Test the screw head and shank size by inserting the screw into one of the keyhole shaped apertures of the Wall Mounting Plates before it is screwed into the wall.

STEP 3:

Once the screws are fixed into the wall, insert the four screw heads through the large opening of the keyhole-shaped apertures, and then slide the AWK-5222 downwards, as indicated to the right. Tighten the four screws for added stability.



Wiring Requirements



WARNING

Safety First!

Be sure to disconnect the power cord before installing and/or wiring your Moxa AWK-5222.



WARNING

Safety First!

Calculate the maximum possible current in each power wire and common wire. Observe all electrical codes dictating the maximum current allowed for each wire size.

If the current goes above the maximum ratings, the wiring could overheat, causing serious damage to your equipment.

You should also pay attention to the following items:

- Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the intersection point.
NOTE: Do not run signal or communications wiring and power wiring in the same wire conduit. To avoid interference, wires with different signal characteristics should be routed separately.
- You can use the type of signal transmitted through a wire to determine which wires should be kept separate. The rule of thumb is that wiring with similar electrical characteristics can be bundled together.
- Keep input wiring and output wiring separate.
- It is strongly advised that you label wiring to all devices in the system when necessary.



ATTENTION

This product is intended to be supplied by a Listed Power Unit marked "Class 2" or "LPS" and rated O/P: 12 to 48 VDC, max 800 mW, 25°C.



ATTENTION

Make sure the external power adaptor (includes power cords and plug assemblies) provided with the unit is certified and suitable for use in your country.

Grounding the Moxa AWK-5222

Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground connection from the ground screw to the grounding surface prior to connecting devices.




ATTENTION

This product is intended to be mounted to a well-grounded mounting surface, such as a metal panel.


Wiring the Redundant Power Inputs

The top two pairs of contacts of the 10-contact terminal block connector on the AWK-5222's top panel are used for the AWK-5222's two DC inputs. Top and front views of the terminal block connector is shown here.



Top View

STEP 1: Insert the negative/positive DC wires into the V-/V+ terminals.



Front View

STEP 2: To keep the DC wires from pulling loose, use a small flat-blade screwdriver to tighten the wire-clamp screws on the front of the terminal block connector.

STEP 3: Insert the plastic terminal block connector prongs into the terminal block receptor, which is located on the AWK-5222's top panel.



ATTENTION

Before connecting the AWK-5222 to the DC power inputs, make sure the DC power source voltage is stable.

Wiring the Relay Contact


The AWK-5222 has one relay output, which consists of the two contacts of the terminal block on the AWK-5222's top panel. Refer to the previous section for detailed instructions on how to connect the wires to the terminal block connector, and how to attach the terminal block connector to the terminal block receptor. These relay contacts are used to indicate user-configured events. The two wires attached to the Relay contacts form an open circuit when a user-configured event is triggered. If a user-configured event does not occur, the Relay circuit will be closed.

Wiring the Digital Inputs

The AWK-5222 has two sets of digital input—DI1 and DI2. Each DI comprises two contacts of the 10-pin terminal block connector on the AWK-5222's top panel. You can refer to the "Wiring the Redundant Power Inputs" section for detailed instructions on how to connect the wires to the terminal block connector, and how to attach the terminal block connector to the terminal block receptor.

Cable Holder Installation (Optional)

You can attach the cable holder to the bottom of the AWK-5222. This helps to keep cabling neat and avoid accidents that result from untidy cables.






STEP 1:

Screw the cable holder onto the bottom of the AWK-5222.

STEP 2:

After mounting the AWK-5222 and plugging in the LAN cable, tighten the cable along the device and wall.



Communication Connections

10/100BaseT(X) Ethernet Port Connection

The 10/100BaseT(X) ports located on the AWK-5222's front panel are used to connect to Ethernet-enabled devices.


Below we show pinouts for both MDI (NIC-type) ports and MDI-X (HUB/Switch-type) ports.

MDI Port Pinouts

MDI-X Port Pinouts

8-pin RJ45

| Pin | Signal | Pin | Signal |
|-----|--------|-----|--------|
| 1 | Tx+ | 1 | Rx+ |
| 2 | Tx- | 2 | Rx- |
| 3 | Rx+ | 3 | Tx+ |
| 6 | Rx- | 6 | Tx- |




RS-232 Connection

The AWK-5222 has one RS-232 (8-pin RJ45) console port located on the front panel. Use either an RJ45-to-DB9 or RJ45-to-DB25 cable to connect the Moxa AWK-5222's console port to your PC's COM port. You may then use a console terminal program to access the AWK-5222 for console configuration.

Console Pinouts for 10-pin or 8-pin RJ45

| 10-Pin | Description | 8-Pin |
|--------|-------------|-------|
| 1 | ----- | |
| 2 | DSR | 1 |
| 3 | RTS | 2 |
| 4 | GND | 3 |
| 5 | TxD | 4 |
| 6 | RxD | 5 |
| 7 | DCD | 6 |
| 8 | CTS | 7 |
| 9 | DTR | 8 |
| 10 | ----- | |



- NOTE**
1. The pin numbers for male DB9 and DB25 connectors, and hole numbers for female DB9 and DB25 connectors are labeled on the connector. However, the numbers are typically quite small, so you may need to use a magnifying glass to see the numbers clearly.
 2. The pin numbers for both 8-pin and 10-pin RJ45 connectors (and ports) are typically not labeled on the connector (or port). Refer to the Pinout diagram above to see how RJ45 pins are numbered.

LED Indicators

The front panel of the Moxa AWK-5222 contains several LED indicators. The function of each LED is described in the table below.

| LED | Color | State | Description |
|---|-------------|----------------|---|
| Front Panel LED Indicators (System) | | | |
| PWR1 | Green | On | Power is being supplied from power input 1. |
| | | Off | Power is not being supplied from power input 1. |
| PWR2 | Green | On | Power is being supplied from power input 2. |
| | | Off | Power is not being supplied from power input 2. |
| PoE | Amber | On | Power is being supplied via PoE. |
| | | Off | Power is not being supplied via PoE. |
| FAULT | Red | Blinking | Cannot get an IP address from the DHCP server (interval: 1 sec) |
| | | Off | There is no error condition. |
| STATE | Green/Red | Green | Software Ready. |
| | | Blinking Green | The AWK has been located by AWK Search Utility (interval: 1sec) |
| | | Red | Booting or Error condition. |
| WLAN1 | Green/Amber | Green On | WLAN1 functions in Client mode. |
| | | Blinking Green | WLAN1's data communication is running in Client mode. |
| | | Amber On | WLAN1 functions in AP/Bridge mode. |
| | | Blinking Amber | WLAN1's data communication is running in AP/Bridge mode. |
| | | Off | WLAN1 is not in use. |
| WLAN2 | Green/Amber | Green On | WLAN2 function is in Client mode. |
| | | Blinking Green | WLAN2's data communication is running in Client mode. |
| | | Amber On | WLAN2 function is in AP/Bridge mode. |
| | | Blinking Amber | WLAN2's data communication is running in AP/Bridge mode. |
| | | Off | WLAN2 is not in use. |
| TP Port (LAN1, LAN2) LED Indicators (Port Interface) | | | |
| 10M | Yellow | On | TP port's 10 Mbps link is active. |
| | | Blinking | Data is being transmitted at 10 Mbps |
| | | Off | TP port's 10 Mbps link is inactive. |
| 100M | Green | On | TP port's 100 Mbps link is active. |
| | | Blinking | Data is being transmitted at 100 Mbps |
| | | Off | TP port's 100 Mbps link is inactive. |

Specifications

WLAN

| | |
|--|---|
| Standards | IEEE 802.11a/g/b for Wireless LAN IEEE 802.11i for Wireless Security IEEE 802.3u for 10/100BaseT(X) IEEE 802.3af for Power-over-Ethernet IEEE 802.1D for Spanning Tree Protocol IEEE 802.1w for Rapid STP |
| Spread Spectrum and Modulation | DSSS with DBPSK, DQPSK, CCK OFDM with BPSK, QPSK, 16QAM, 64QAM |
| Operating Channels (Central Frequency) | US: 2.412 to 2.462 GHz (11 channels) 5.18 to 5.24 GHz (4 channels) EU: 2.412 to 2.472 GHz (13 channels) 5.18 to 5.24 GHz (4 channels) |
| Security | 64-bit and 128-bit WEP encryption, WPA /WPA2 Personal or Enterprise (IEEE 802.1X/ RADIUS, TKIP and AES) |
| Protocol | |
| General Protocols: | Proxy ARP, DNS, HTTP, HTTPS, IP, ICMP, SNMP, TCP, UDP, RADIUS, SNMP, PPPoE, DHCP, LLDP |
| AP-only Protocols: | ARP, BOOTP, DHCP, dynamic VLAN-Tags for 802.1X-Clients, STP/RSTP (IEEE 802.1D/w) |
| Data Rates | 802.11b: 1, 2, 5.5, 11 Mbps 802.11a/g: 6, 9, 12, 18, 24, 36, 48, 54 Mbps |
| Transmit Power | 802.11b: 1 to 11 Mbps: Typ. 18±1.5 dBm 802.11g: 6 to 24 Mbps: Typ. 18±1.5 dBm 36 to 48 Mbps: Typ. 16±1.5 dBm 54 Mbps: Typ. 15±1.5 dBm 802.11a: 6 to 24 Mbps: Typ. 16±1.5 dBm 36 to 48 Mbps: Typ. 14±1.5 dBm 54 Mbps: Typ. 13±1.5 dBm |
| Receiver Sensitivity | 802.11b: -92 dBm @ 1 Mbps, -90 dBm @ 2 Mbps, -88 dBm @ 5.5 Mbps, -84dBm @ 11 Mbps 802.11g: -87 dBm @ 6 Mbps, -86 dBm @ 9 Mbps, -85 dBm @ 12 Mbps, -82dBm @ 18 Mbps, -80 dBm @ 24 Mbps, -76 dBm @ 36 Mbps, -72dBm @ 48 Mbps, -70 dBm @ 54 Mbps 802.11a: -87 dBm @ 6 Mbps, -86 dBm @ 9 Mbps, -85 dBm @ 12 Mbps, -82dBm @ 18 Mbps, -80 dBm @ 24 Mbps, -76 dBm @ 36 Mbps, -72dBm @ 48 Mbps, -70 dBm @ 54 Mbps |

Interface

| | |
|-------------------|---|
| Default Antenna | 2dBi dual-band, Omni-directional antenna |
| Antenna Connector | RP-SMA (male) |
| Connection | 10-pin Removable Terminal Block |
| Alarm Contact | 1 relay output (capacity: 1A @24VDC) |
| Digital Input | 2 electrically-isolated inputs 3 to -30V for state "0" (OFF) 13 to 30V for state "1" (ON) Max. input current: 8 mA |
| Console | RS-232 (RJ45 type) |
| LAN Port | 10/100BaseT(X) auto negotiation speed |
| LED Indicators | PWR1, PWR2, PoE, FAULT, STATE, WLAN1, WLAN2, 10M, 100M |

Power

| | |
|-----------------------|--|
| Input Voltage | 12 to 48 VDC, redundant dual DC power inputs or 48 VDC Power-over-Ethernet (IEEE 802.3af) |
| Input Current | 800mA @ 12-48VDC |
| Input Current @ 24VDC | 0.3 A |

Overload Current 1.6 A

Protection

| | |
|--------------------------------|---------|
| Reverse Polarity Protection | Present |
|--------------------------------|---------|

Mechanical

| | |
|--------------|--|
| Casing | IP30 protection, aluminum case |
| Dimensions | 62.05 x 135 x 105 mm (2.44 x 5.31 x 4.13 in) |
| Weight | 880g |
| Installation | DIN-Rail, or wall mounting |

Environmental

| | |
|------------------------------|---|
| Operating Temperature | Standard models: 0 to 60°C (32 to 140°F) Wide Temp. Models: -40 to 75°C (-40 to 167°F) |
| Storage Temperature | -40 to 85°C (-40 to 185°F) |
| Ambient Relative Humidity | 5 to 95% (non-condensing) |

Regulatory Approvals*

| | |
|--------|----------------------|
| Radio | EN300.328 |
| EMC | EN301 489-1/-17 |
| EMI | FCC Part 15 |
| Safety | EN60950-1, UL60950-1 |

* **Please check Moxa's website for the most up-to-date certification status.**

WARRANTY

5 years

For details see <http://www.moxa.com/warranty>



ATTENTION

The AWK-5222 is **NOT** a portable mobile device and should be located at least 20 cm away from the human body. The AWK-5222 is **NOT** designed for the general public. To deploy AWK-5222s and establish a wireless network safely, a well-trained technician is required for installation.



ATTENTION

Use the antennas correctly: Two dual-band 2.4 GHz & 5 GHz antennas, are included with the product. Either antenna can be installed in MAIN1 or MAIN2. If you want to use a single band antenna, please use 2.4 GHz antennas for IEEE 802.11b/g mode and 5 GHz antennas for IEEE 802.11a mode. In order to improve the quality of the signal received by the Main antennas, you may connect additional antennas to AUX1 and AUX2.

Technical Support Contact Information **www.moxa.com/support**

Moxa Americas:

Toll-free: 1-888-669-2872

Tel: 1-714-528-6777

Fax: 1-714-528-6778

Moxa China (Shanghai office):

Toll-free: 800-820-5036

Tel: +86-21-5258-9955

Fax: +86-21-5258-5505

Moxa Europe:

Tel: +49-89-3 70 03 99-0

Fax: +49-89-3 70 03 99-99

Moxa Asia-Pacific:

Tel: +886-2-8919-1230

Fax: +886-2-8919-1231